


Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle	B964727NU	1 Set				
2	Valve G1/2 8x20	B961469NU	1 Pcs.				
3	Tub.spout J150-compl.	B964966AA	1 Set				
3a	Tub.spout J200-compl.	B960416AA	1 Set				
4	Perlator M22x1-B	B964945AA	1 Pcs.				
5	O-Ring Ø13x2.5	B960137NU	1 Pcs.				
6	Connecting set	B960544NU	1 Set				
6a	Connecting set	B960415NU	1 Set				
7	Fl.pexhose G3/8 M10x1-L445mm	B960535NU	1 Pcs.				
8	Beaded chain L460mm	A960933NU	1 Pcs.				



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle	B964727NU	1 Set				
2	Valve G1/2 8x20	B961469NU	1 Pcs.				
3	Body-wall basin		1 Pcs.				
4	Chain holder	B960537AA	1 Pcs.				
5	Tub.spout J150-compl.	B964966AA	1 Set				
5a	Tub.spout J200-compl.	B960416AA	1 Set				
6	Perlator M22x1-B	B964945AA	1 Pcs.				
7	O-Ring Ø13x2.5	B960137NU	1 Pcs.				
8	Connecting set	B960544NU	1 Set				
8a	Connecting set	B960271NU	1 Set				
9	Flex hose G3/8 M10x1C/8x12/L400	A963305AA	1 Pcs.				
10	Beaded chain L460mm		1 Pcs.				